



# Minolta Maxxum STsi Main Battery Replacement

This guide will explain how to replace the main battery that powers the camera.

Written By: Conner Lawston



## INTRODUCTION

If the camera seems to have lost power, it is necessary to replace the main battery. This can be accomplished in a couple simple steps.

---



### TOOLS:

- [Coin](#) (1)
-

## Step 1 — Main Battery



- Use the edge of a coin to twist open the battery compartment on the bottom of the camera. (Twist counterclockwise)

## Step 2



- When the compartment opens, pull the AA battery out of its slot.

To reassemble your device, follow these instructions in reverse order.